





FALCO

FWT50




26.5.2017

- D** Montageanleitung
- FR** Notice de montage
- NL** Handleiding voor de montage
- CZ** Montážní návod
- HU** Szerelési útmutató
- TR** Montaj talimatı
- GB** Assembly Instructions
- IT** Istruzioni di montaggio
- PL** Instrukcja montażu
- SK** Návod na montáž
- RO** Instrucțiunile de montaj
- RU** Инструкции по монтажу





20 min.



1





ZE X4 	Z X4 8x32 	NC 4x18 X4 	Y X4 	ZA X1 	NA 4x19 X9 	N 3x20 X6 	X X10
B X18 	A X18 	H 8.3x13 X8 	ZD X4 	PC X4 	RC X4 	TB X1 	TA X1
C X18 	W X2 	YA 4x27 X4 	Z X18 	RC X4 	RC X4 	TA X1 	W X1







2





3









4






5






6




8



9





10



NC 4x16 X4	PC X4	YA 4x27 X4
ZD X4	NA 4x13 X8	W X2

11



ZA X1	TB X1	ZE X4
NA 4x13 X1	TA X1	Z X4